



## STARTING MOTOR 61-62 01-10 (OHV): 63 01-10

A.M. No. 316 1142

DELCO-REMY No. 1107201

KEY NO.	DELCO-REMY NUMBER	A.M. GROUP	A.M. PART NUMBER	DESCRIPTION	QUAN. REQ.
1	1928966	3.020	311 9543	END, Commutator	1
2	1906945			BRUSH	4
2		3.020	320 2006	BRUSH SET (Incl. 4 Brushes)	1
3	1926617	3.020	320 6082	HOLDER, Brush (Ground)	2
4	1926618	3.020	320 6083	HOLDER, Brush (Insulated)	2
5	1926622	3.020	311 9545	SPRING, Brush	2
6	1928015	3.020	320 6084	SUPPORT, Brush Holder (Package)(Incl. all parts listed below which are coded with a #)	2
7	1926605	3.020	320 6085	#LEAD, Brush Ground	2
8	1933761	3.020	320 0936	COIL, Field (Incl. 4 Coils)	1
9				COIL, Shunt (Part of Key No. 8)	
10	1935851	3.020	320 0935	ARMATURE	1
11	1932209	3.020	320 6086	SPRING, Shift Lever Assist	1
12	1935853	3.020	320 0938	DRIVE ASSEMBLY	1
13	1927849	3.020	320 6087	COLLAR, Drive End Pinion Stop	1
14	1927848	3.020	320 6088	RING, Drive End Pinion Stop Retainer	1
15	1927850	3.020	320 6092	COLLAR, Drive End Thrust	1
16	1945013	3.020	320 1283	HEAD, Drive End (Drive Housing)(Incl. all parts coded with a *)	1
17	1119798	3.020	320 2630	SWITCH, Solenoid (use 320 5022)	1
18	1932208	3.020	320 6285	SPRING, Plunger Return (Replaces 320 6093)	1
19	1932200	3.020	320 4021	PLUNGER	1
20	1932205	3.020	320 6094	LEVER, Shift	1
21	455106	17.472	G455106	PIN, Plunger Attaching To Shift Lever (Not Available)	1
22	1932197	3.020	320 6098	STUD, Shift Lever	1
23	120217	17.820	G120217	#LOCKEASHER, Support Attaching Screw (Not Available)	4