

KEY NO.	HOLLEY NO.	A.M. NO.	DESCRIPTION	PER CAR
	85R-1314	320 6352	Choke Kit (For R-2387 and R-2557)(Includes all parts listed below which are coded with a <b>■</b> )	1
	85R-1313	320 6353	Choke Kit (For R-2387-1 and R-2557-1)(Includes all parts listed below which are coded with a <b>■</b> )	1
	85R-1302	320 6355	Choke Kit (For *R-2387-1 and *R-2557-1)(Includes all parts listed below which are coded with a <b>■</b> )	1
	85C-1301	320 6351	Choke Shaft Kit (Includes all parts listed below which are coded with a <b>■</b> )	1
	85T-1303	320 6356	Throttle Shaft Kit (Includes all parts listed below which are coded with a <b>■</b> )	1
	85R-1263	320 4367	Dashpot Kit (Includes all parts listed below which are coded with a <b>©</b> )	1
		316 9636	Metering Jet Pkg. (Incl. 1-Holley 22R-40-61 Metering Jet, 2 sizes lean for alt. 2,000 to 5,000 ft., & 1-Holley 22R-40-59 Metering Jet, 4 sizes lean for alt. 5,000 to 10,000 ft.)	1
1	1R-841A	320 4846	Air Horn and Tube Assembly	1
2	2R-387A		<b>■</b> Choke Plate Assembly	1
3	3R-457A		<b>■</b> Choke Shaft and Lever Assembly	1
4	4R-745B		<b>■</b> Choke Lever	1
5	5R-357	320 4400	° Throttle Stop Screw	1
6	5R-816	320 4401	° <b>■</b> Fast Idle Cam Retainer	1
7	5R-928	320 4412	° Fast Idle Screw (Phillip Head)	1
8	5R-837	320 4402	<b>■</b> ° * Throttle Plate Screw	2
9	5R-847	320 6358	Carb Body Screw and Lockwasher	8
10	5R-848	320 4403	<b>■</b> <b>■</b> <b>■</b> ° Thermostat Cap Clamp Screw	2
11	5R-849	320 4404	<b>■</b> ° Choke Lever Screw	1
11	5R-849	320 4404	° Choke Lever Screw	1
12	5R-906	320 4406	<b>■</b> ° * Choke Plate Screw	2
13	8R-941		<b>■</b> <b>■</b> <b>■</b> <b>■</b> + Thermostat Cap Gasket	1
14	8R-942		<b>■</b> <b>■</b> <b>■</b> <b>■</b> + Choke Housing Gasket	1
15	8R-982		<b>■</b> Carb. Body Gasket	1
16	8R-955	315 3999	<b>■</b> + Flange Gasket	1
17	9R-164		<b>■</b> Throttle Plate	1
18	10R-1090	320 6359	<b>■</b> Throttle Shaft and Lever Assembly	1
19	12R-2674A		Carb. Body and Shaft Assembly	1
20	15R-59	320 6360	* Idle Needle	1
21	16R-346A-3	320 4844	Float Assembly	1
22	18R-104-AS	320 5127	* <b>■</b> Fuel Inlet Needle and Retainer Assembly	1
22	19R-223	320 6362	Fuel Inlet Fitting	1
23	22R-40-63	320 6363	Main Jet	1
24	23R-321	320 6364	* Pump Discharge Valve	1
25	25R-322A	320 4424	Power Valve Piston Assembly	1
26	25R-336-AS	320 6365	* <b>■</b> Power Valve Assembly	1
27	27R-250	320 6366	* <b>■</b> Pump Piston Cup	1
28	28R-94	320 3181	* Pump Inlet Ball	1
29	29R-726	320 6367	* Float Hinge Pin	1
30	31R-211A	320 4845	Pump Rod and Stem Assembly	1
31	33R-403	320 6368	<b>■</b> * Pump Link	1
32	36R-340	320 4407	°* <b>■</b> Pump Piston Cup Retainer	1
33	38R-108	320 3191	φ Throttle Stop Screw Spring	2
34	38R-108	320 3191	φ Idle Needle Spring	1
35	38R-975	320 4408	° Pump Return Spring	1
36	39R-11	320 4409	° <b>■</b> Pump Lever Nut	1
37	41R-428	320 6369	<b>■</b> Fast Idle Cam	1
38	43R-301	320 6370	<b>■</b> Fast Idle Link	1
39	46R-636	320 6371	<b>■</b> Pump Lever Nut Lock Washer	1
40	47R-176		<b>■</b> <b>■</b> <b>■</b> Choke Housing Plate	1
41	47R-188A	320 4455	<b>■</b> Thermostat Cap Assembly (Use on Carburetor 2387 and 2557)	1
41	47R-192	320 4456	<b>■</b> Thermostat Cap Assembly (Use on Carburetor 2387-1 *and 2557-1*)	1
41	47R-193	320 4457	<b>■</b> Thermostat Cap Assembly (Use on Carburetor 2387-1 and 2557-1)	1