

KEY NO.	HOLLEY NO.	A.M. NO.	DESCRIPTION	PER CAR
62	38R-110	320 3192	φV Throttle Stop Screw Spring	1
63	38R-569	320 3196	φZX Diaphragm Return Spring	1
64	38R-583	320 3197	φV Fast Idle Cam Lever Spring	1
65	38R-587	320 3198	φV Pump Lever Adjusting Spring	1
66	38R-803	320 3203	φZ Float Spring (Blue)	1
67	38R-760	320 3202	φZ Air Vent Rod Spring	1
68	39R-5	320 6344	° Choke Thermostat Shaft Hexagon Nut	1
69	39R-160	320 3206	φZ Fuel Valve Seat Adjusting Nut	1
70	40R-108	320 3208	φ° Choke Thermostat Lever Spacer	1
71	41R-240	320 6347	Pump Cam (Red)	1
72	41R-229A	320 6346	° Fast Idle Cam Assy.	1
73	43R-203		▣ Choke Rod	1
74	43R-276		Z Air Vent Rod	1
75	46R-248	320 6349	° Choke Shaft Nut Shakeproof Lock Washer	1
76	47R-116A	320 3222	° Thermostat Housing Assy. (Cp.) (Identified by 57-M1 on Cover)	1
77	48R-31	320 3227	φ*▣ Choke Rod Retainer	2
78	49R-328		° Thermostat Housing Clamp	1
79	49R-425		Z Air Vent Rod Clamp	1
80	57R-35	320 6350	Z Filter Screen	1
81	59R-34		Z Baffle Plate	1
82	63R-382		V Pump Operating Lever	1
83	75R-37	320 3240	Vφ Pump Operating Lever Retainer	1