

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
(.002) 60 Thru 62 01-10 (OHV).....		6	320 0310	
(.002) 63 01-10 (OHV): 64 01-10 (OHV-196-Note 1.136-1 Type 1).....		6	320 4025	
(.002) 64 01-10 (OHV-196-Note 1.136-1 Type 2): 65 01 (OHVC-196).....		6	320 5236	
(.002) 65 01-80 (OHV-232): 64-65 10 (OHV-232).....		6	320 4958	
(.002) 65 01-10 (OHV-199).....		6	320 5446	
(.002) 63 Thru 65 10 (V8-287): 65 80 (V8-287).....		8	320 4495	
(.002) 60-61 20.....		8	320 0113	
(.002) 64-65 10 (V8-327-WDT): 60 Thru 65 80 (V8-327-WDT)..... (Replaces 320 2316)		8	320 1775	
(.002) 64-65 10 (V8-327-W4B): 60 Thru 65 80 (V8-327-W4B).....		8	320 0314	
(.005) 60 Thru 62 01 (LHE).....		6	320 0904	
(.005) 63 01 (LHE): 64 01 (LHE-Note 1.136-1 Type 1).....		6	320 4031	
(.005) 64 01 (LHE-Note 1.136-1 Type 2): 65 01 (LHE).....		6	320 5242	
(.005) 61-62 01 (LHE-WST-Export 3-3/4" Stroke)(LHE-WOD-Export 3-3/4" Stroke)		6	320 1102	
(.005) 60 Thru 62 01-10 (OHV).....		6	320 0311	
(.005) 63 01-10 (OHV): 64 01-10 (OHV-196-Note 1.136-1 Type 1).....		6	320 4026	
(.005) 64 01-10 (OHV-196-Note 1.136-1 Type 2): 65 01 (OHVC-196).....		6	320 5237	
(.005) 65 01-80 (OHV-232): 64-65 10 (OHV-232).....		6	320 4959	
(.005) 65 01-10 (OHV-199).....		6	320 5447	
(.005) 63 Thru 65 10 (V8-287): 65 80 (V8-287).....		8	320 4496	
(.005) 60-61 20.....		8	320 0114	
(.005) 60 80 (WDT).....		8	320 1776	
(.005) 64-65 10 (V8-327-WDT): 61 Thru 65 80 (V8-327-WDT).....		8	320 2317	
(.005) 64-65 10 (V8-327-W4B): 60 Thru 65 80 (V8-327-W4B).....		8	320 0315	
(.010) 60 Thru 62 01 (LHE).....		6	320 0905	
(.010) 63 01 (LHE): 64 01 (LHE-Note 1.136-1 Type 1)..... (Use 320 5243)		6	320 4032	#
(.010) 60 Thru 62 01-10 (OHV).....		6	320 0312	
(.010) 63 01-10 (OHV): 64 01-10 (OHV-196-Note 1.136-1 Type 1).....		6	320 4027	
(.010) 64 01 (LHE-Note 1.136-1 Type 2): 65 01 (LHE).....		6	320 5243	
(.010) 64 01-10 (OHV-196-Note 1.136-1 Type 2): 65 01 (OHVC-196).....		6	320 5238	
(.010) 65 01-80 (OHV-232): 64-65 10 (OHV-232).....		6	320 4960	
(.010) 65 01-10 (OHV-199).....		6	320 5448	
(.010) 63 Thru 65 10 (V8-287): 65 80 (V8-287).....		8	320 4497	
(.010) 60-61 20.....		8	320 0115	
(.010) 64-65 10 (V8-327-WDT): 60 Thru 65 80 (V8-327-WDT)..... (Replaces 320 1777)		8	320 2318	
(.010) 64-65 10 (V8-327-W4B): 60 Thru 65 80 (V8-327-W4B).....		8	320 0316	
(.020) 60 Thru 62 01 (LHE).....		6	320 0921	
(.020) 63 01 (LHE): 64 01 (LHE-Note 1.136-1 Type 1) .. (Replaces 320 3878)		6	320 4033	
(.020) 64 01 (LHE-Note 1.136-1 Type 2): 65 01 (LHE).....		6	320 5244	
(.020) 60 Thru 62 01-10 (OHV).....		6	320 0914	
(.020) 63 01-10 (OHV): 64 01-10 (OHV-196-Note 1.136-1 Type 1)..... (Replaces 320 3797)(Use 320 5239)		6	320 4028	
(.020) 64 01-10 (OHV-196-Note 1.136-1 Type 2): 65 01 (OHVC-196).....		6	320 5239	
(.020) 65 01-80 (OHV-232): 64-65 (OHV-232).....		6	320 4961	
(.020) 65 01-10 (OHV-199).....		1	320 5449	
(.020) 63 Thru 65 10 (V8-287): 65 80 (V8-287).....		8	320 4498	
(.020) 60-61 20.....		8	311 9628	
(.020) 64-65 10 (V8-327-WDT): 60 Thru 65 80 (V8-327-WDT)..... (Replaces 320 1778)		8	320 2319	
(.020) 64-65 10 (V8-327-W4B): 60 Thru 65 80 (V8-327-W4B).....		8	320 0481	
(.030) 60-61 20.....		8	311 9629	