

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
(Auto-Lite IBP-4107) 61 20-80		1	316 2037	
(Auto-Lite IBP-4109) 62 80: <b>163 80 (CAN-Note 3.030-1)</b>		1	316 4150	
(Auto-Lite IBP-4109A): <b>164-165 10-80 (V8-CAN)</b>		1	317 3163	
(Auto-Lite IDC-4601) <b>165 01-10 (OHV-199-Can): 165 01-10-80 (OHV-232-Can)</b>		1	317 9094	
(Delco Remy 1110289)(Use For Delco Remy 1110308) 63 Thru 65 01 (Six-196): 63-64 10 (Six-196) .....( <b>Replaces 317 0250</b> )		1	316 7666	#
(Delco Remy 1110299) 63 Thru 65 01 (LHE)		1	316 7665	
(Delco-Remy 1110320) 65 01-10 (OHV-199): 65 01-10-80 (OHV-232): 64 10 (OHV-232) ..... ( <b>Use 318 0070</b> )		1	317 3220	
(Delco Remy 1111025) 63 Thru 65 10-80 (V8)		1	316 7667	
(Delco Remy 1112434) 60-61 01-10 (OHV) ..... ( <b>Use 316 4204</b> )		1	315 7914	
(Delco Remy 1112435) 62 01-10 (OHV)		1	316 4204	
(Prestolite IDC-4601-A) <b>165 01-10-80 (OHV-199-Can)(OHV-232-Can)</b>		1	318 0286	

**ARM, Distributor Advance**

60 Thru 62 01 (LHE): <b>163 Thru 165 01 (CAN)</b>		1	315 9547	
---	--	---	----------	--

**SPACER, Distributor Advance Arm**

60 Thru 62 01 (LHE): <b>163 Thru 165 01 (CAN)</b>		1	315 9548	
---	--	---	----------	--

**SHAFT, Distributor**

(Auto-Lite IAT-3086LA): <b>162 01-10-80 (CAN)</b> ...(Incl. Governor And Cam)		1	320 9067	
---	--	---	----------	--

**3.031 CONTACT SET, Ignition**

60 Thru 62 01 (LHE): <b>164-165 01-10-80 (Can):</b> 60 Thru 62 20-80: <b>162 10 (Can)</b>		1	320 1801	
60 Thru 62 01-10 (OHV-Pre Assembled)		1	320 2807	
63 Thru 65 01-10 (Six): 65 80 (OHVC-232)		1	320 4202	
<b>165 01-10 (OHV-199-Can): 165 01-10-80 (OHV-232-Can)</b>		1	320 9165	
63 Thru 65 10-80 (V8)		1	320 0197	

**3.032 CAP, Distributor**

60 Thru 62 01 (LHE): <b>162 10 (CAN)</b>		1	320 3937	
60 Thru 62 01-10 (OHV)		1	314 1430	
63 Thru 65 01-10 (Six): 65 80 (OHVC-232) ..... ( <b>Use 320 6903</b> )		1	320 4197	
<b>163 01 (LHE-Can): 164-165 01 (Can): 163 Thru 165 10-80 (Six-Can)</b>		1	320 9053	
<b>164-165 10-80 (V8-Can):</b> 60 Thru 62 20-80 .....( <b>Replaces 320 1796</b> )		1	320 2808	#
63 Thru 65 10-80 (V8)		1	320 0192	

**CONTACT, Distributor Cap**

60 Thru 62 01 (LHE): <b>164-165 01-10-80 (Can):</b> 61-62 20-80		1	320 1798	
60 20-80		1	311 8871	

**SPRING, Distributor Cap Contact**

60 Thru 62 01 (LHE): <b>164-165 01-10-80 (Can):</b> 60 Thru 62 20-80		1	311 8872	
--	--	---	----------	--

**3.033 CONDENSER, Distributor**

60 Thru 62 01 (LHE): 60 Thru 65 10-20-80 (V8). ( <b>Replaces 320 1800, 320 0198</b> )		1	320 4585	
60 Thru 62 01-10 (OHV): 63 Thru 65 01-10 (Six): 65 80 (OHV-232) ..... ( <b>Replaces 311 8585</b> )		1	320 4584	
<b>162 Thru 165 01-10-80 (Can)</b>		1	320 9088	
<b>165 01-10 (OHV-199-Can): 165 01-10-80 (OHV-232-Can)</b>		1	320 9166	