

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
CAM, Directional Signal Switch Canceling				
60 01		1	314 6253	
61 Thru 63 01: 61-62 10-20-80		1	316 1330	
60 10-20-80		1	315 7884	
PIN, Directional Signal Switch Canceling (In Steering Wheel)				
64-65 01		1	317 0335	
63 Thru 65 10-80 (LAW)		1	316 8867	
64-65 10-80 (WAW)		1	317 2949	
INSULATOR, Directional Signal Switch				
61-62 10-20-80	3.406	1	316 1370	
BRACKET, Directional Signal Switch				
60 10-20-80		1	320 1943	
ARM, Directional Signal Switch (Incl. Return Spring)				
60 01		1	320 1766	
60 10-20-80 (Note 3.321-1 Type 1)		1	320 1948	
60 10-20-80 (Note 3.321-1 Type 2)		1	320 2816	
SPRING, Directional Signal Switch Return				
60 01		1	320 0421	
60 10-20-80		1	320 1949	
SPRING, Directional Signal Switch Arm To Mounting Plate				
60 01		1	320 0587	
60 10-20-80		1	320 1951	
CLIP, Directional Signal Switch Arm To Mounting Plate				
60 01		1	320 0588	
60 10-20-80		1	320 1950	
HARNESS, Directional Signal Switch Extension Wire				
64 10-80 (WAW)		1	317 2487	
65 10-80 (WAW)		1	317 6537	
3.324 LEVER, Directional Signal				
60 01		1	315 2223	
61 01-10-20-80 (Gray)		1	316 0641	
61 Thru 63 01 (Black): 61-62 10-20-80 (Black)		1	316 2303	
64-65 01		1	317 1813	
60 10-20-80		1	315 7669	
63 10-80 (WST)(WOD)		1	316 7115	
63 10-80 (WAT)		1	316 7717	
64-65 10-80 (LAW)		1	317 2911	
64-65 10-80 (WAW)		1	317 2938	
ATTACHING PARTS				
Directional Signal Switch Lever To Switch				
SCREW, Machine..... 61 Thru 63 01-10-20-80: 64-65 10-80 (LAW)	(Replaces 316 0745)	3.321	2	316 9148
SCREW, Machine..... 60 10-20-80		17.626	1	G425575 NA
WASHER, Lock..... 64 10 (LAW): 65 10-80 (LAW)		17.820	2	G131095 NA