

| GROUP NO. — DESCRIPTION — YEAR and MODEL | PRIMARY GROUP NO. | PER CAR | PART NO. | CODE |
|--|-------------------|---------|----------|---------------------|
| SCREW, Tapping..... 64-65 01 | 17.671 | 1 | G274773 | |
| SCREW, Tapping..... 60-61 10-20-80..... | 17.671 | 2 | 800 0093 | |
| SCREW, Tapping..... 62 Thru 64 10-80..... | 17.671 | 4 | G9514051 | NA |
| SCREW, Tapping..... 65 10-80 | 17.660 | 2 | G161901 | NA |
| BRACKET, Courtesy Lamp To Instrument Panel | | | | |
| 64-65 01 (LHD) | | 1 | 350 6921 | |
| ATTACHING PARTS | | | | |
| Bracket To Instrument Panel (Right Side) | | | | |
| SCREW, Sealed..... 64-65 01 (LHD) | | 2 | 400 0720 | |
| LENS, Courtesy Lamp Assembly | | | | |
| 61-62 07 (Note 3, 349-2 Type 2): 63 07 (Notes 3, 349-2 Type 2 And 3, 349-3 Type 1) | | 2 | 320 2908 | |
| 63 07 (Notes 3, 349-2 And 3, 349-3 Type 2): 64 07 | | 1 | 320 4508 | |
| HARNESS, Courtesy Lamp Assembly Switch To Domelamp Harness | | | | |
| 61 Thru 63 01 (LHD-Note 3, 349-2 Type 1) | | 1 | 346 4709 | |
| WIRE, Courtesy Lamp Assembly (Incl. Socket) | | | | |
| 61-62 07 (Note 3, 349-2 Type 2): 63 07 (Note 3, 349-2 Type 2 And 3, 349-3 Type 1) | | 1 | 320 2907 | |
| 63 07 (Notes 3, 349-2 Type 2 And 3, 349-3 Type 2) | | 1 | 320 4507 | |
| HARNESS, Courtesy Lamp Assembly Wire | | | | |
| 64-65 01 (LHD) | | 1 | 317 1118 | |
| 64 02-05-06-08 (RHD) | | 1 | 317 1119 | |
| 64 07-09 (RHD): 65 01 (RHD) | | 1 | 317 3319 | |
| 60-61 10-20-80 (Note 3, 349-1 Type 1) | | 1 | 343 6144 | |
| 60-61 10-20-80 (Note 3, 349-1 Type 2) | | 1 | 345 0893 | |
| 62 10-80 | | 1 | 348 6174 | |
| 63-64 10-80 | | 1 | 317 0962 | (Replaces 349 7607) |
| 65 10-80 (LHD) | | 1 | 317 6533 | |
| 65 10 (RHD) | | 1 | 317 6540 | |
| (Left) 61 07 (Note 3, 349-2 Type 2) | | 1 | 346 3504 | |
| (Left) 62-63 07 (Note 3, 349-2 Type 2) | | 1 | 347 4673 | |
| (Right) 61 Thru 63 07 (Note 3, 349-2 Type 2) | | 1 | 346 3505 | |
| HARNESS, Courtesy Lamp Assembly To Courtesy Lamp Assembly | | | | |
| 61 01 (LHD-Note 3, 349-2 Type 1) | | 1 | 346 4711 | |
| 62-63 01 (LHD-Note 3, 349-2 Type 1) | | 1 | 347 4766 | |
| HARNESS, Courtesy Lamp Assembly Switch To Connector | | | | |
| 60-61 10-20-80 | | 1 | 343 6145 | |
| ADAPTER, Courtesy Lamp Assembly Wire | | | | |
| 60-61 10-20-80 | 6.329 | 1 | 312 3479 | |
| BULB, Courtesy Lamp Assembly | | | | |
| (GE 89) 63 01 | 3.215 | 2 | G142452 | |
| (GE 90) 61 Thru 63 01 | 3.215 | 2 | G142453 | |
| (GE 211-1) 64 01 | 3.215 | 2 | G9414045 | (Use 320 9536) |
| (GE 1004) 64-65 01: 60 Thru 65 10-80 | 3.215 | 2 | G455136 | |
| 3.352 LIGHTER ASSEMBLY, Cigar (Incl. Knob And Element) | | | | |
| 60 01 | | 1 | 315 7930 | |