

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
SPRING, Horn Blowing Ring				
60 Thru 63 01: 60 Thru 62 10-20-80.....	1	313 1589	
64-65 01: 63 Thru 65 10-80	1	316 9434	
SPRING, Horn Blowing Ring Contact				
60-61 01.....(Replaces 313 3542)	3.412	1	313 3642	
62-63 01.....	1	316 3663	
64-65 01.....	1	317 0332	
RETAINER, Horn Blowing Ring				
60 01.....	1	313 4891	
61 01.....	1	316 0741	
62-63 01.....	3.400	1	316 3669	
64-65 01.....	1	317 0485	
60 Thru 62 10-20-80	1	315 0138	
ATTACHING PARTS				
Horn Blowing Ring To Steering Wheel				
SCREW, Machine..... 60 01.....	17.614	3	G173028 NA	
WASHER, Lock..... 60 01.....	17.820	3	G131095 NA	
INSULATOR, Horn Blowing Ring Retainer				
60 01.....	2	313 4892	
61 Thru 63 01: 60 Thru 62 10-20-80.....	1	315 3889	
INSULATOR, Horn Blowing Ring Spoke				
61 Thru 63 01: 60 Thru 62 10-20-80.....	1	315 7619	
ATTACHING PARTS				
Horn Blowing Ring Spoke Insulator To Steering Wheel				
STUD, Drive..... 61 Thru 63 01: 60 Thru 62 10-20-80.....	17.720	1	G443094 NA	
INSULATOR, Horn Blowing Ring Plate Spacer				
61 Thru 63 01 (21/32" Long): 60 Thru 62 10-20-80	3	315 7932	
61 01 (1/4" Long)	3	316 0740	
INSULATOR, Horn Blowing Ring Contact Plate To Cam				
61-62 10-20-80.....	1	316 1370	
INSULATOR, Horn Blowing Ring Brush				
63 Thru 65 10-80.....	1	316 7356	
PIN, Horn Blowing Contact				
64-65 01.....	1	317 0333	
PLATE, Horn Blowing Ring Contact				
60 Thru 62 10-20-80.....(Replaces 315 7885)	1	316 1332	
63 Thru 65 10-80.....	1	316 8003	
(Lower) 64-65 01.....	1	317 0331	
(Upper) 64-65 01.....	3.400	1	317 0341	