

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
BEARING, Accelerator Control Shaft				
63 10-80 (RHD-V8-Note 4.050-4 Type 1)..... (Use 317 2126)	4.050	2	316 3822	
ATTACHING PARTS				
Bearing To Bracket				
WASHER, Plain..... 63 10-80 (RHD-V8-Note 4.050-4 Type 1).....(Replaces 800 0157)	17.814	2	400 0480	
PIN, Cotter 63 10-80 (RHD-V8-Note 4.050-4 Type 1).....	17.460	2	G103373 NA	
4.057 CABLE, Accelerator				
64 01 (LHD-LHE)..... (Use 317 7272)	1	317 3024	
65 01 (LHD-LHE).....	1	317 7272	
64 01 (LHD-OHV): 65 01 (LHD-OHV-196-LDT).....(Replaces 317 3025)	1	317 7271	#
65 01 (LHD-OHV-196-WDT).....	1	318 0026	
63 10-80 (RHD-V8-Note 4.050-2 Type 2).....	1	316 9610	
64 01-10 (RHD-OHV-196): 65 01 (RHD).....	1	317 3026	
64 10 (RHD-V8).....	1	317 2176	
65 01 (RHD-OHV-199): 65 10 (RHD-OHV-232).....	1	317 6070	#
65 10 (RHD-OHV-287).....	1	317 3027	
ATTACHING PARTS				
Cable To Dash				
CLIP 64-65 01 (LHE)(OHV-196): 64 10 (RHD-OHV-196): 65 10 (RHD-OHV-232)(RHD-OHV-287).....	8.192	1	312 8734	
CLIP 63 10-80 (RHD-V8-Note 4.050-4 Type 2): 64 10 (RHD-V8).....	1	317 0388	
WASHER, Plain..... 63 10-80 (RHD-V8-Note 4.050-4 Type 2): 64 10 (RHD-V8).....	17.814	1	G120394 NA	
Cable To Valve Cover				
CLIP 63 10-80 (RHD-V8-Note 4.050-4 Type 2): 64 10 (RHD-V8): 65 10 (RHD-OHV-287-WAT).....	3.022	1	313 0379	
Cable To Control Shaft Lever				
PIN, Clevis 64-65 01: 64 10 (RHD-OHV-196): 65 10 (RHD).....	16.300	1	316 4193	
PIN, Cotter 64-65 01: 64 10 (RHD-OHV-196): 65 10 (RHD).....	17.460	1	G137127 NA	
PIN, Locking..... 65 01 (LHD-OHV-196-WDT).....	1	400 0793	
WASHER, Plain..... 64-65 01: 64 10 (RHD-OHV-196): 65 10 (RHD).....	17.814	1	G446152 NA	
Cable To Carburetor Pin				
WASHER, Plain..... 63 10-80 (RHD-V8-Note 4.050-4 Type 2): 64 10 (RHD-V8): 65 10 (RHD-OHV-287-WAT).....	17.814	1	G446152 NA	
PIN, Cotter 63 10-80 (RHD-V8-Note 4.050-4 Type 2): 64 10 (RHD-V8).....	17.460	1	G103361 NA	
PIN, Cotter 65 10 (RHD-OHV-287-WAT).....	17.460	1	G137127 NA	
NUT, Hexagon..... 63 10-80 (RHD-V8-Note 4.050-4 Type 2): 64 10 (RHD-V8).....	17.412	1	G120614 NA	
Cable To Control Shaft Bracket				
BOLT, Hexagon ... 64-65 01 (LHE)(OHV-196): 64 10 (RHD-OHV-196): 65 10 (RHD).....	17.038	1	G180018 NA	
WASHER, Lock 64-65 01 (LHE)(OHV-196): 64 10 (RHD-OHV-196): 65 10 (RHD).....	17.820	1	G120380 NA	
NUT, Hexagon..... 64-65 01 (LHE)(OHV-196): 64 10 (RHD-OHV-196): 65 10 (RHD).....	17.406	1	G120375	
CLIP 64 01: 64 10 (RHD-OHV-196)..... (Use 317 3016)	1	316 9596	
CLIP..... 65 01 (LHE)(OHV-196): 65 01 (RHD-OHV-199): 65 10 (RHD-OHV-232)(RHD-OHV-287).....	1	317 3016	#
Cable To Bellcrank				
PIN, Clevis 64-65 01 (LHE)(OHV-196): 64 10 (RHD-OHV-196) ...	16.300	1	316 4193	
WASHER, Plain..... 64-65 01 (LHE)(OHV-196): 64 10 (RHD-OHV-196) ...	17.814	1	G446152 NA	
PIN, Cotter 64-65 01 (LHE)(OHV-196): 64 10 (RHD-OHV-196) ...	17.460	1	G137127 NA	