

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
62 10 (RHD)		1	316 4750	
63 10 (RHD-OHV-Six)		1	316 8080	
64 10 (OHV-232): 65 10 (LHD-Six-LDT)		1	317 5758	
65 10-80 (LHD-OHV-232-WDT-Note 4.050-9) ... (Incl. Bearing).....		1	317 5775	
65 10-80 (LHD-OHV-232-WDT-Note 4.050-10)		1	318 0033	
65 01 (RHD-OHV-199): 65 10 (RHD-OHV-232)		1	317 7578	

ATTACHING PARTS

Bracket To Dash

SCREW, Tapping.....	60 10 (RHD-3 Req.): 61 10 (RHD-2 Req.): 62 10 (RHD)	17.671	2	G274773	NA
SCREW, Tapping.....	65 01 (OHV-199)(LHD-OHV-232): 63 10 (RHD-OHV-Six): 64 10 (OHV-232): 65 10-80 (LHD-Six).....	17.670	3	G189119	NA

Bracket To Cylinder Head

BOLT, Hexagon	64 01-10 (RHD-196): 65 01 (RHD-OHV-196)	1.063	1	315 1412	
WASHER, Lock	64 01-10 (RHD-196): 65 01 (RHD-OHV-196)	17.820	1	G131100	NA
WASHER, Plain	64 01-10 (RHD-196): 65 01 (RHD-OHV-196)	1.034	1	24 545	
NUT, Hexagon	64 01-10 (RHD-196): 65 01 (RHD-OHV-196)	17.406	1	G120370	

Bracket To Manifold Cover

BOLT	64 01-10 (RHD-196): 65 01 (RHD-OHV-196)	17.038	1	G180022	NA
SCREW, Machine.....	65 01 (RHD-OHV-199): 65 10 (RHD-OHV-232)	17.626	2	400 0987	
WASHER, Plain.....	64 01-10 (RHD-196): 65 01 (RHD-OHV-196)	17.814	1	G446188	NA
WASHER, Lock	65 01 (RHD-OHV-199): 65 10 (RHD-OHV-232)	17.186	2	G120214	NA

SUPPORT, Carburetor Control Shaft

64 01 (LHD-OHV-WDT-Note 4.070-1 Type 2).....	1	317 3345	
64 01 (LHD-OHV-LDT-Note 4.070-1 Type 2).....	1	317 2912	

ATTACHING PARTS

Shaft To Support

BUSHING	64 01 (Note 4.070-1 Type 2): 65 01 (LHD-OHV-196)	4.050	1	316 7590	
WASHER, Plain.....	64 01 (Note 4.070-1 Type 2).....	17.814	2	400 1091	
PIN, Cotter	64 01 (Note 4.070-1 Type 2).....	17.460	1	G103373	NA

LEVER, Carburetor Control Shaft To Kickdown Switch

60 20-80 (WOD-WDT)(WAT-WDT).....	1	315 8419	
60 20-80 (WOD-W4B)(WAT-W4B): 61-62 20-80 (WOD)(WAT).....	1	315 4268	

NUT, Carburetor Control Shaft To Kickdown Switch Lever

60 Thru 62 20-80 (WOD)(WAT)	17.410	1	G120613	NA
-----------------------------------	--------	---	---------	----

4.080 SPRING, Carburetor Pull Back

60 01-20-80: 60 10 (LHD): 61 10 (LDT): 62 01 (LHD-LHE-WST-5" Long) (LHD-LHE-WAT-5" Long): 62 01 (LHD-WOD): 62 10-80: 63 01 (LHD-LHE-WOD)(OHV): 63 10 (OHV-Six): 63 80 (LHD-5" Long)(RHD-5" Long-Note 4.050-4 Type 1): 64 10 (LHD-OHV-196)	(Replaces 316 0520, 316 2201)	1	313 9296	
60 10 (RHD): 61 10 (RHD-WDT)	1	314 3516	
61 01 (RHD)	5.092	1	312 5077	
61 01 (LHD-LHE)(OHV): 61 10 (LHD-WDT): 61 20-80	10.470	1	315 5195	
62 01 (LHD-LHE-WST-4-1/4" Long)(LHD-LHE-WAT-4-1/4" Long): 63 01 (LHD-LHE-WST)(LHD-LHE-WAT): 63 10-80 (4-1/4" Long-V8): 64-65 10-80 (LHD-V8): 64 01-10 (RHD-OHV-196-LDT): 65 01 (RHD-OHV-196-LDT)	1	316 4949	

NOTE 4.080-1: Two Types of Springs were used on the 62 01 (LHD-LHE-WST)(LHD-LHE-WAT) Models. They can be identified as follows:
 Type 1: The overall length of the Spring is either 5" or 5-1/2" long.
 Type 2: The Overall length of the Spring is 4-1/4".