

FUEL - EXHAUST

4.174

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
Tube To Front Suspension Bracket				
CLIP..... 61 80.....	1	15 708	
BOLT, Hexagon..... 61 80.....	17.038	1	G180020	NA
WASHER, Lock..... 61 80.....	17.820	1	G120380	NA
NUT, Hexagon..... 61 80.....	17.406	1	G120375	
Sending Unit And Outlet Tube				
CLIP..... 63 Thru 65 10-80 (L3S).....	4.152	1	47 272	
Tube To Wheelhouse				
CLIP..... 62-63 80.....	4.152	2	47 272	
Tube To Rear Sill				
CLIP..... 63 Thru 65 10-80 (LHD-L3S).....	1	310 7665	
Tube To Front Support Bracket				
CLIP..... 65 10 (Six-WVW-1 Req.): 65 10 (V8-2 Req.): 65 80 (V8-1 Req.): 65 10 (Six-WEW-2 Req.): 65 80 (OHV-232-WEW-1 Req.).....	AR	47 272	
HOSE, Gasoline (Bulk-Order Per Foot)				
60 Thru 65 01-10-20-80.....	AR	320 2187	
ATTACHING PARTS				
Hose To Floor Pan				
CLIP..... 62 10-80 (W3S).....	3.210	1	312 3849	
SCREW, Tapping..... 62 10-80 (W3S).....	(Replaces 800 0091) 17.671	1	400 1031	
UNION, Extension Tube				
60-61 20-80.....	17.796	1	G137414	
CLAMP, Gasoline Hose				
60 Thru 65 01-10-20-80.....	AR	315 5854	
4.174 TUBE, Fuel Pump To Carburetor				
60 Thru 62 01 (LHD-LHE).....	1	315 5519	
61-62 01 (RHD).....	(Use 316 5980) 2.062	1	316 1497	#
60 Thru 62 01 (OHV): 60 10 (RHD-LDT): 61-62 10 (LHD-LDT-WST) (LHD-LDT-WOD).....	(Replaces 315 9859, 316 1045)	1	316 2963	
63 01 (LHD-LHE).....	1	316 7740	
63 01 (OHV-WDT): 60 10 (RHD-WDT): 61 Thru 63 10 (OHV-WDT-Six).....	(Replaces 316 1046)	1	316 2967	
63 01 (OHV-LDT): 63 10 (OHV-WST-LDT-196)(OHV-WOD-LDT-196).....	1	316 7499	
63 01 (RHD).....	1	316 7958	
64-65 01 (LHD-LHE).....	1	317 1859	
64 01 (OHV-LDT).....	1	317 3496	
65 01 (OHV-196-LDT).....	1	317 5825	
64-65 01 (OHV-196-WDT): 64 10 (OHV-196-WDT).....	(Replaces 317 3464)	1	317 5828	
60 10 (LHD-LDT-Note 4.174-1).....	1	315 8423	
60 10 (LHD-LDT-Note 4.174-2).....	1	315 8698	
60 10 (LHD-WDT-Note 4.174-1).....	1	315 8424	
60 10 (LHD-WDT-Note 4.174-2).....	1	315 8699	
60 10 (RHD-LDT).....	(Discontinued)	1	315 9438	#
60 10 (RHD-WDT).....	1	315 9521	
61 10 (LDT-WAT).....	1	316 1044	
61-62 10 (RHD-LDT-WST)(RHD-LDT-WOD).....	1	316 2288	
62-63 10 (LDT-WAT): 162 10 (CAN-LHD-LDT): 163 10 (CAN).....	1	316 2965	

- NOTE 4.174-1: Used with Fuel Pump 315 8342 (Carter MPF-2988S).
- NOTE 4.174-2: Used with Fuel Pump 315 8546 (Carter MPF-3025S).
- NOTE 4.174-3: Used prior to Engine Code No. 608L04.
- NOTE 4.174-4: Used beginning with Engine Code No. 608L04.