

ILLUSTRATIONS INDEX

GROUP 16 AUTOMATIC TRANSMISSION (Continued)

VALVE ASSEMBLY 64 01-10 (SIX); 65 ALL MODELS (SIX).....	IL 16 - 17
VALVE ASSEMBLY 64-65 10-80 (V8-WCGS)	IL 16 - 18
VALVE ASSEMBLY 64-65 10-80 (V8-WFGS)	IL 16 - 19

GROUP 20 BODY SHEET METAL

AUXILIARY FLOOR PANELS 63 THRU 65 18-88 (L3S)	FIG. 20.430 - 5
AUXILIARY FLOOR PANELS 60 THRU 62 10-20-80 WAGON (L3S).....	FIG. 20.430 - 3
AUXILIARY FLOOR PANELS 60 THRU 62 10-20-80 WAGON (W3S).....	FIG. 20.430 - 4
BODY SIDE SHEET METAL 61 THRU 63 02-06	FIG. 20.175 - 1
BODY SIDE SHEET METAL 61 THRU 63 05.....	FIG. 20.175 - 1a
BODY SIDE SHEET METAL 61 THRU 63 04.....	FIG. 20.175 - 1b
BODY SIDE SHEET METAL 61 THRU 63 08.....	FIG. 20.175 - 1c
BODY SIDE SHEET METAL 61 THRU 63 07.....	FIG. 20.175 - 1d
DASH AND FRONT WHEELHOUSE PANEL 64-65 01	IL 20 - 1
DASH ASSEMBLY AND WHEELHOUSE PANEL 61 THRU 63 01.....	FIG. 20.120 - 1
DASH ASSEMBLY AND WHEELHOUSE PANEL 63 THRU 65 10-80.....	FIG. 20.120 - 4
DASH ASSEMBLY AND WHEELHOUSE PANEL 60 THRU 62 10-20-80.....	FIG. 20.120 - 3
FRAME ASSEMBLY 61 THRU 63 07.....	FIG. 20.600 - 1
REAR QUARTER PANEL 60 THRU 62 10-20-80 SEDAN.....	FIG. 20.270 - 3
REAR QUARTER PANEL ASSEMBLY 60 THRU 62 10-20-80 WAGON.....	FIG. 20.265 - 3
REAR QUARTER PANELS 63-64 10-80 SEDAN.....	FIG. 20.272 - 3
REAR QUARTER PANELS 63-64 10-80 WAGON.....	FIG. 20.272 - 4
REAR QUARTER PANELS 64-65 05-08	IL 20 - 12
REAR QUARTER PANELS 64-65 07-09	IL 20 - 7
REAR QUARTER PANELS 65 15-16-17-19 (EXCEPT MARLIN).....	IL 20 - 10
REAR QUARTER PANELS 65 59-7 (MARLIN).....	IL 20 - 10
ROOF PANEL AND REAR SHELF PANEL 63-64 10-80 SEDAN.....	FIG. 20.420 - 5
ROOF PANEL AND REAR SHELF PANEL 61 THRU 63 02-05-06-09	FIG. 20.420 - 1
ROOF PANEL AND SUPPORTS 63 THRU 65 10-80 WAGON	FIG. 20.420 - 6
ROOF PANEL AND SUPPORTS 61 THRU 63 04-08.....	FIG. 20.420 - 2
ROOF PANEL AND SUPPORTS 60 THRU 62 10-20-80 WAGON.....	FIG. 20.420 - 4
ROOF PANEL, SUPPORTS AND SHELF PANEL 60 THRU 62 10-20-80 SEDAN	FIG. 20.420 - 3
ROOF PANEL, SUPPORTS AND REAR SHELF PANEL 65 15-16-85-86	IL 20 - 9
ROOF PANEL, SUPPORTS AND REAR SHELF PANEL 65 19-89 (EXCEPT MARLIN).....	IL 20 - 9
ROOF PANEL, SUPPORTS AND REAR SHELF PANEL 65 59-7 (MARLIN).....	IL 20 - 12
UNDERBODY PANELS 60 01.....	FIG. 20.005 - 1
UNDERBODY PANELS 61 THRU 63 01	FIG. 20.005 - 2
UNDERBODY PANELS 63 10-80 - (REFER IL 20-8).....	FIG. 20.005 - 5
UNDERBODY PANELS 60 THRU 62 10-20-80 (L3S)	FIG. 20.005 - 3
UNDERBODY PANELS 60 THRU 62 10-20-80 (W3S)	FIG. 20.005 - 4
UNDERBODY PANELS 64-65 02-05-06-08-09	IL 20 - 6
UNDERBODY PANELS 64-65 07.....	IL 20 - 5
UNDERBODY PANELS 63 THRU 65 10-80	IL 20 - 8
UNISIDE 63 THRU CURRENT 16-86: 64-65 02-06	IL 20 - 2
UNISIDE 64-65 07: 65 17-87.....	IL 20 - 3
UNISIDE 64-65 09-19-89 (EXCEPT MARLIN)	IL 20 - 4
UNISIDE 65 59-7 (MARLIN)	IL 20 - 11
UNISIDE ASSEMBLY 60 THRU 62 15-18-25-28-85-88.....	FIG. 20.170 - 3
UNISIDE ASSEMBLY 63 THRU 65 15-18-85-88: 64-65 05-08.....	FIG. 20.170 - 4

GROUP 22 WINDSHIELD WIPER - COWL VENT - INSTRUMENT PANEL

ELECTRIC WINDSHIELD WIPER 64-65 ALL MODELS	IL 22 - 3
ELECTRIC WINDSHIELD WIPER 63 10-80.....	FIG. 22.027 - 3
INSTRUMENT PANEL, GLOVE BOX AND LOCK ASSEMBLY 60-61 10-20-80	FIG. 22.056 - 3
INSTRUMENT PANEL, GLOVE BOX AND LOCK ASSEMBLY 62-63 10-80.....	FIG. 22.056 - 4
INSTRUMENT PANEL, GLOVE BOX AND LOCK ASSEMBLY 63 10-80 (WAC)	FIG. 22.056 - 5
INSTRUMENT PANEL, GLOVE BOX AND LOCK ASSEMBLY 64-65 01	IL 22 - 5
INSTRUMENT PANEL, GLOVE BOX AND LOCK ASSEMBLY 65 10 (EXCEPT MARLIN)	IL 22 - 6
INSTRUMENT PANEL, GLOVE BOX AND LOCK ASSEMBLY 65 80.....	IL 22 - 7
INSTRUMENT PANEL OPENING COVERS 65 10-80	IL 22 - 8
VACUUM WINDSHIELD WIPER 64-65 01	IL 22 - 1
VACUUM WINDSHIELD WIPER 63 THRU CURRENT 10-80.....	IL 22 - 2
WINDSHIELD WIPER 60 THRU 62 01-10-20-80: 63 01.....	FIG. 22.027 - 1