

GROUP 3

CANADIAN PECULIAR

KEY NO.	AUTO-LITE NUMBER	A.M. GROUP	A.M. PART NUMBER	DESCRIPTION	QUAN. REQ.
11	IAO-11			WASHER, Drive Shaft Thrust (Outer-Upper)	1
12	IAT-2023LT	3.046	320 9061	CONTROL, Distributor Vacuum	1
13	VC-49			SPRING, Vacuum Control	1
14	VC-46			WASHER, Vacuum Control (.032 in. Thick)	AR
14	VC-46A			WASHER, Vacuum Control (.010 in. Thick)	AR
14	VC-46B			WASHER, Vacuum Control (.065 in. Thick)	AR
15	IAT-30			GASKET, Vacuum Control (1/32 in. Thick)	1
16	IAZ-33			PLUG, Vacuum Control	1
17	X-1270			WASHER, Vacuum Control Mounting Screw (#10)	2
18	8X-872			SCREW, Vacuum Control Mounting (#10-32 x 1/4)	2
19	IBT-1007			CLAMP, Cap (Incl. Spring And Hinge)	1
20	8X-304			SCREW, Clamp And Breaker Plate Mounting (#8-32 x 3/8)	1
21	12X-1275			LOCKWASHER, Plate Screw (#8)	1
22	XA-949	3.042	320 9183	PIN, Gear	1
23	IBR-1003B	3.042	320 9053	CAP ASSEMBLY, Distributor (Incl. Key No's. 39 And 40)	1
24	IGE-15			WASHER, Clamp Screw Plain (#6)	1
25	IGC-175A			SCREW, Spring Clamp	1
26	8X-3504			SCREW, Breaker Contact Lock	1
28	IAT-3076DS	3.033	320 9088	CONDENSER	1
29	IAT-81B	3.030	320 9054	LEAD, Primary (Low Tension Wire)	1
30	IGS-99			SPACER, Cam	1
31	IAT-2086LA	3.030	320 9060	SHAFT, Main	1
32	IAT-100			COVER, Oil Wick	1
34	8X-304			SCREW, Clamp And Breaker Plate Mounting (#8-32 x 3/8)	1
36	IBT-49			TAG, Identification	1
37	IAT-1088B			BASE ASSEMBLY, Distributor (Incl. Key No's. 41 And 42)	1
38	GE-107S	3.042	320 9062	GEAR, Distributor	1
39	IAO-20	3.032	311 8872	SPRING, Contact (Part of Key No. 23)	1
40	IAT-87	3.032	320 1798	CONTACT (Plunger)(Part of Key No. 23)	1
42	IG-579A	3.030	311 1952	BUSHING, Distributor Base (Bronze)(Upper) (Part of Key No. 37)	1
	IG-90B			THRUST WASHER (Main Shaft)(Not Shown)	2