# CRANKSHAFT AND CAMSHAFT 60 thru Current 01: 60 thru Current 10 (OHV-196)




(A) Part of BEARING SET 1.041
(B) Part of BEARING SET 1.023
(C) Part of CRANKSHAFT 1.042
(D) Part of GASKET SET (OVERHAUL) 1.060
(E) Part of FLYWHEEL ASSY. 1.056
(F) Part of COVER ASSY. 1.120
(H) Used only on WST and WOD
(I) Used only on WPS and WAC
(J) Part of BLOCK ASSY. 1.020
(K) Part of ENGINE ASSY. 1.002
(L) Used on 60 thru 6301 (WST)(WOD): 6201 (WAT)
60 thru 6210 (OHVC-WST)(OHVC-WOD)



Copyright 1963 American Motors Corp.



Printed in U.S.A.